


Air Slide 2 Active Infrared Door Sensor with Flex Eye (touchless Switch)




the Air-Slide provides safety and convenience in one unit. The Air-Slide Active Infrared Door Sensor from OPTEX includes a built-in Touchless Switch. When the door is closed, the sensor operates as a virtual door switch, activating the door only when someone approaches the door and presents a hand near the sticker.

Double slide door



Single slide door



Step 1



AIR SLIDE 2 does not detect pedestrians walking across.

Step 2




When a pedestrian approach his/her hand, the door opens.

Step 3



The door opens and the presence detection area keeps the door opened.

Step 4



After the pedestrian walked through the door, the door is closed and then the presence detection area disappears.

Air Slide 2 Active Infrared Door Sensor with Flex Eye (touchless Switch)

Energy Saving

Eliminates unwanted activations due to cross traffic to improve air conditioning efficiency.

Shop owner

I would like to avoid unnecessary door openings due to cross traffic to improve air conditioning efficiency. My shop is facing with a busy street.



Germ Free

Eliminates one of the only cross contamination points on a low energy or knowing act door.

Nurse

Touch switch is contamination points for a knowing act or low energy door. I want to open a door without touching anything.



Safety

Provides safety throughout the threshold area keeping the door open until all people have moved away.


Chef

I want an automatic door for my kitchen but what I need is a limited detection area because my staff is walking around in front of a door.




Air Slide 2 Active Infrared Door Sensor with Flex Eye (touchless Switch)

Detection Area



Double slide door

Single slide door



unit : m

A	2.00	2.30	2.50	3.00
B	0.13	0.16	0.17	0.21
C	0.38	0.46	0.50	0.60
D	0.71	0.86	0.94	1.13
E	0.84	1.01	1.09	1.31
F	1.34	1.62	1.76	2.11
G	1.75	2.11	2.29	2.75
H	0.92	1.11	1.20	1.45
I	1.49	1.80	1.95	2.34
J	2.06	2.48	2.69	3.23

Charts show the values in the following area angle adjustment settings ; Depth :0° Width :0°

Air Slide 2 Active Infrared Door Sensor with Flex Eye (touchless Switch)

1 Secondary Activation area angle adjustment

1-1. Secondary Activation area depth angle adjustment
When adjusting the 2nd row close to the door, see Dipswitch settings table dipswitch 16 for the easier adjustment.

NOTE Make sure that the Secondary Activation area does not overlap with the door / header, and there is no highly reflecting object near the detection area otherwise ghosting / signal saturation may occur.

REFERENCE Area depth adjustment with INFRARED FINDER (Separately available)

- Turn the depth angle adjustment screw to the right (Deep) to place the Secondary Activation area most away from the door.
- Set INFRARED FINDER sensitivity to "H" (High) and place it on the floor as shown below.

- Turn the depth angle adjustment screw to the left (Shallow) until the emitting area is placed at the position where INFRARED FINDER is in the low detection status (Slow Red Blinking).

1-2. Secondary Activation area width angle adjustment
The width of the activation Secondary Activation area can both be moved at the same time 7° either left or right in 2 step.

2 Secondary Activation area width elimination

To adjust the Secondary Activation area width, use the adjustment screws.

NOTE When setting the Secondary Activation area width, make sure to turn the adjustment screws until it clicks. [1][2] cannot be eliminated separately, neither can [7][8].

3 FLEX EYE angle adjustment

Make sure to select the FLEX EYE angle depending on the door type and the intended touchless plate position otherwise the sensor does not send an output when a hand is waved.

3-1. FLEX EYE width adjustment

3-2. FLEX EYE Depth adjustment

NOTE After adjust the angle, please check the FLEX EYE is on the best position for your use. Please check the door will be open, when you are detected in the area between 2nd to 4th row. Operation indicator color will be purple, when all the adjustment are OK.





















3-3. Affix the touchless plate on the appropriate position after adjusting the FLEX EYE.

CAUTION Risk of getting caught.	Make sure to affix the touchless plate where a head is not caught by the door during door closing.
---	--

Air Slide 2 Active Infrared Door Sensor with Flex Eye (touchless Switch)

4 Dipswitch settings

Dipswitch settings table

Dipswitch	Function	Setting				Comment
		Low	Middle	High	S-High	
Dipswitch 1	Secondary Activation area Sensitivity					Set the sensitivity according to the mounting height. Values below dipswitch are reference only.
Dipswitch 2		67" to 82"	67" to 82"	77" to 810"	82" to 9'10"	
Dipswitch 3	Presence timer	30sec.	60sec.	180sec.	600sec.	All rows have the presence detection function. The presence timer can be selected from 4 settings.
Dipswitch 4						
Dipswitch 5	Frequency	Setting1	Setting2	Setting3	Setting4	When using more than one sensor close to each other, set the frequency different for each sensor.
Dipswitch 6						
Dipswitch 7	Rain mode	Normal	Rain			Set this switch to Rain if the sensor is used in a region with a lot of rain.
Dipswitch 8	Snow mode	Normal	Snow			Set this switch to Snow if the sensor is used in a region with snow or a lot of insects.
Dipswitch 9	Row adjustment	6rows	5rows	4rows	3rows	Set the depth rows with dipswitches 9 and 10.
Dipswitch 10						
Dipswitch 11	BLUEZONE (1st row)	OFF	ON			When dipswitch 11 is set to ON, the BLUEZONE (1st row) is active and looks through the threshold.
Dipswitch 12	Secondary Activation output	N.O.	N.C.			Select "N.O.," "N.C." for Secondary Activation output.
Dipswitch 13	FLEX EYE Sensitivity	Low	Middle	High	S-High	Adjust sensitivity for "FLEX EYE" detection.
Dipswitch 14						
Dipswitch 15	FLEX EYE mode	ON	OFF			Select the FLEX EYE mode ON or OFF. See FLEX EYE MODE.
Dipswitch 16	Installation mode	OFF	ON			Set dipswitch 16 to ON to adjust the 2nd row. During the installation mode only the 2nd row remains active and the operation indicator shows yellow. After setting the row switch dipswitch 16 OFF.

Copyright (C) 2017 OPTEX GROUP CO., LTD.

